

**BB** encore

# sparkle decors special instructions

The nature of the near plain colour of sparkle decors is such that more care needs to be taken during the final all-over sanding process.

To achieve this you will need additional finishing materials. Included with this leaflet are an additional two 320grit discs and two fine Scotchbrite pads to complete the process.

Please follow the instructions included in our installation guide for final all-over 320grit sanding to ensure thorough finishing.

Dust extraction is vital. Always thoroughly dust down when changing to finer sanding grits; a quick all-over wipe with clean water also helps to remove dust debris.

Next, as with darker decors such as Anthracite, thoroughly dry sand the worksurface with a Scotchbrite pad. Dust down and remove final traces of dust with a damp cloth.

Finally, attach a folded clean white wipe from the installation kit to the base of the sander and dry polish the worksurface to provide an all-over even sheen finish.

The idea of the additional process is to bring the finish up to an acceptable standard before applying BB Complete Polish.

As an option BB Complete Polish can be applied. Do not apply polish before sanding is completed to the finish your customer expects. Early application of

polish can disguise an incorrectly sanded surface but will lead to a customer complaint as it wears with time and exposes the lesser surface finish.

Please ensure that splashbacks and upstands are fully sanded before installation. The correct standard is difficult to achieve in situ.

**For further advice please contact our customer service team on 01933 232 272.**



**BB**  
**BUSHBOARD**



For technical support on Bushboard products, please  
contact the Customer Service Team on:  
tel: 01933 232 272  
fax: 01933 232 286  
email: [samples@bushboard.co.uk](mailto:samples@bushboard.co.uk)  
or log onto [www.bushboard.co.uk](http://www.bushboard.co.uk)